


HOW TO USE THE OPENING ANGLE RESTRICTOR ON THE 165-DEGREE HINGE




STEP 1



Note: Close the door to an angle of 120° or less to activate the integrated opening angle restrictor switch.

STEP 2



Note: Adjust the restriction switch to the desired opening angle setting (130°, 165°).

OPENING RESTRICTION SETTINGS

