


HOW TO USE THE OPENING ANGLE RESTRICTOR ON A STANDARD HINGE




STEP 1



Note: Close the door to an angle of 75° or less to activate the integrated opening angle restrictor switch.

STEP 2



Note: Adjust the restriction switch to the desired opening angle setting (95°, 105°, or 85°).

OPENING RESTRICTION SETTINGS

